



SINGER | Confidence™



Model 7470

Feature	Benefit
225 Stitch Patterns	A large variety of stitches including basic, decorative, stretch and alphanumeric.
6 Fully Automatic 1-step Buttonholes	Buttonhole sewing is a 1-step simple process, providing reliable results. Each side is sewn in the same direction, creating beautifully balanced buttonholes.
<i>Drop & Sew</i> ™ Bobbin System	Simply place the wound bobbin into the bobbin case, then run the bobbin thread through its guide. The machine will automatically draw up the bobbin thread for you!
LCD Screen	The LCD provides clear and easy viewing of stitch patterns, including stitch width and length.
Built-In Alphabet	Personalize projects by adding a monogram, name or phrase with the built-in block style alphabet.
Push-Button Stitch Selection	With just a simple push of a button you have selected the stitch as well as the optimum settings for length and width.
Automatic Needle Threader	After effortlessly threading the machine this feature automatically threads the eye of the needle.
Adjustable Stitch Length	Optimal settings for length are automatically adjusted when choosing a stitch. They can be overridden to personalize length choice.
Adjustable Stitch Width	Optimal settings for width are automatically adjusted when choosing a stitch. They can be overridden to personalize width choice.
Center Zigzag Taper	When tapering with the zigzag stitch, the stitch tapers to the center, not the left or right. This provides a more attractive look when tapering into or out of a point.



SINGER | Confidence™

Model 7470

Feature	Benefit
Automatic Tacking Stitch Function	Tie-off <i>decorative</i> stitches with just a push of a button. With 4 tiny tacking stitches, the start and end of the pattern is reinforced ensuring quality stitching and preventing unraveling.
Automatic Tie-off Function	The Automatic Tie-off Function reinforces the start and end of seams (straight stitches) for stronger stitching.
<i>Exclusive</i> Buttonhole Underplate	This is a SINGER® developed system that sandwiches fabric between a lower plate and the foot, to ensure perfect buttonholes on multiple layers of fabric as well as delicate and stretch fabrics.
7mm Stitch Width	When sewing select stitches, the wide stitches are bolder and more pronounced.
Programmable Needle Up and Down	Select whether the needle is up or down when the machine stops. It is beneficial to have the needle stop in the down position when appliquéing, quilting or pivoting fabric.
20 Character Memory	A memory bank holds full names and simple phrases
3-Step Infinite Length Bar-Tack Buttonhole	Create buttonholes with endlessly long sides. This is ideal when sewing non-traditional sized buttonholes.
Electronic Twin Needle Control	With just the touch of a button create two parallel rows adding a decorative touch
13 Needle Positions	Needle position can be adjusted for techniques, such as inserting zippers, cording and topstitching.
Automatic Tension	This system ensures stable stitch quality when straight stitching no matter what type of fabric is being used



SINGER | Confidence™

Model 7470

Feature	Benefit
Editing Capabilities	Editing is simple. A cursor button can be moved through the 20-space memory. If a stitch or letter needs to be removed, use the editing button.
Mirror Image	Select stitches can be mirror imaged for decorative stitching
Continuous Pattern	Select stitches can be sewn either as a single pattern or continuously
Automatic Presser Foot Pressure Control	The amount of pressure exerted on the fabric by the presser foot against the feed dogs is automatic. Sew from the lightest weight tricots to the heaviest denim without making adjustments.
Jam-proof Bobbin System	The bobbin case floats above the hook, precluding thread jams. The machine will not jam, even when sewing on sheer fabric or no fabric at all.
2 <i>StayBright™</i> LED Lights	The long-lasting bulbs (100,000 hours) stay cool, regardless how long the machine is operated.
Extra-High Presser Foot Lifter	When the Presser Foot Lifter is held in the extra-high position it offers more clearance, which is needed when placing multiple layers of bulky fabric under the presser foot.
Drop Feed Dogs	A conveniently located lever will lower the feed dogs for free-motion embroidery, monograms, and for attaching buttons.
Heavy Duty Metal Frame	This rigid support holds all the mechanisms in perfect alignment for perfect, skip-free sewing.
Automatic Bobbin Winding Clutch	Needle bar automatically disengages when winding the bobbin, making bobbin winding more convenient.
Electronic Stitch Formation	Digital electronic control of the stepper motors that control the pattern formation allows for perfectly formed patterns every time.



SINGER | Confidence™

Model 7470

Feature	Benefit
Pattern Override Memory	The machine remembers, so you don't have to! Select a pattern, override the width and/or length, and the machine will remember those changes. Select a different pattern and then return to the overridden pattern—the override settings will still be in place as long as the machine is not turned off.
Box Feed	This is a feed dog motion that moves the feed dogs in a box motion, rather than the historic arc motion. Box motion assures perfect feeding because the feed dogs are always in perfect and equal contact with the fabric and presser foot.
Optimum Power Control	A control system that senses when additional power is required to maintain speed through thick or changing fabric conditions. This feature is most useful when sewing through multiple (6-8) layers of fabric.
Accessories	Auxiliary Spool Pin Spool Pin Felt Discs (2) Small, Medium and Large Thread Spool Caps (3) General Purpose Foot Satin Special Purpose Foot Zipper Foot Blind Hem Foot Buttonhole Foot 4 Standard 15J Bobbins Needle Package Screwdriver Lint Brush/Seam Ripper Dust Cover
Snap-On Presser Feet	Change from one to another effortlessly with a simple push of the foot release button.
On Board Storage	Accessories are always within reach
Warranty	25-year limited warranty including 5 year electronic and 1 year labor



SINGER

7470 Stitch Chart

Basic					

Stretch				

Buttonhole								

Decorative																			

Alpha-Numeric																				
A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U
V	W	X	Y	Z	À	È	Ì	Ò	Ù	Ä	Ë	Ï	Ö	Ü	Ñ	Í	Ú	É	Â	Û
-	.	,	'	?	!	&	/	□	0	1	2	3	4	5	6	7	8	9		